


**Twistlocks are operated by pulling a set of chains.**  
 Los twistlocks se abren y cierran accionando las cadenas instaladas en cualquiera de las cabezas del spreader.

MODEL	A	B
BA-012H(20')M	5852	2258
BA-012H(40')M	11984	2258

**TEC CONTAINER S.A.**

Tel: + 34 91 302 16 38  
 Fax: + 34 91 766 42 79  
 teccontainer@teccontainer.com  
<http://www.teccontainer.com>



**MANUAL SPREADER FOR  
 BRIDGE/GANTRY CRANE**  
 SPREADER MANUAL  
 PARA PUENTE GRÚA

**BA-012H(X')M**